

## Change to Status Indicator for Certain Machines




### Notice

Production of status indicators for certain machines has been discontinued, and starting in January 2018, we will begin shipping machines with a different status indicator.

If it is necessary to replace a status indicator before the change, it will be replaced with the new status indicator.

### Before the change / after the change

The appearance and dimensions of the status indicators will change.

	Status indicator before the change		Status indicator after the change
Part No.	DHALCE30201-0 (production discontinued)	ERPM-010016-0 (production discontinued)	ESYM-010006-0
Appearance			
Height	228 mm	132 mm*	219 mm

\* For the DFD6040 and DFD6060, the height will be greater after replacing the status indicator with the status indicator after the change.

When replacing the status indicator, please ensure the space required for installation.

### Applicable model

Series	Applicable model	Parts to be replaced at the same time*
3000 series	DAD3240/DAD3360/DAD3650/DAD3660	Installation bracket
6000 series	DFD6341	None
	DFD6560/DFD6760	Installation bracket
	DFD6040/DFD6060	External cover, connection cable
8000 series	DFG8390/DFG8830/DTG8460	Installation bracket
Other	DPM2140/DPM2190	Installation bracket

There is no change to the status indicators of models other than those indicated above.

\*It is possible to install a changed status indicator without replacing the installation bracket, but the status indicator's nameplate will be visible from the front of the machine. Please take the direction of the nameplate into consideration when using it.

### Inquiries

Please contact your local DISCO sales representative or DISCO customer engineer if you have any questions regarding this matter.